

INSTALLATION INSTRUCTIONS

FUEL PRESSURE
VACUUM GAUGE
TEMPERATURE GAUGE
OIL PRESSURE GAUGE
VOLTMETER GAUGE
AMMETER GAUGE
FUEL LEVEL

GENERAL MOUNTING INSTRUCTIONS

These gauge kits are supplied with hardware for two different methods of mounting.




FIGURE 1

NOTE: Single, Dual and Triple Mounting Panels are available for replacement Gauges.
Single Panel SUN MODEL CP 7552
Dual Panel SUN MODEL CP 7551
Triple panel SUN MODEL CP 7550

2. Connect the mounting panel to the dashboard using the two sheetmetal screws (drilling might be required).
3. Assemble the gauge as described above.

CONVENTIONAL MOUNT FOR PANEL OR IN-DASH MOUNTING

Attach the gauge to the mounting panel or dashboard using the U-bracket and the two lock-washers and nuts (Figure 1).

LIGHT CONNECTIONS

1. Connect one wire of the light assembly to the dash light circuit. This enables you use your dash dimmer control for your gauge(s).
2. Connect the other wire to engine/chassis ground.

GAUGE PANEL MOUNTING INSTRUCTIONS

1. Select the location of the mounting panel for the best possible visibility from the normal driving position.

NOTE: Not all dashboards are properly grounded. Avoid painted or insulated surfaces.